polkaudio
the speaker specialists™

RC65*i*
Mounting Template
Follow these steps before installing the RC65*i.*

1) Determine speaker location.
   Be sure that it does not interfere with studs/joists.
2) Hold or tape the template to the mounting location.
   Be sure the template is level.
3) Trace along the outside of the template.
4) Carefully cut a hole ensuring that it is no larger than the shape you traced.
5) Remove the speaker grilles.
6) Attach the speaker wires to the spring clips on the back of the speaker. Use RED for the positive (+) wire and BLACK for the negative (–) wire.
7) Loosen the six screws until the wall clamps swing freely.
8) Rotate the six mounting clamps inward and insert the speakers into the wall opening.
9) Level the speakers and tighten the six screws until snug.
   CAUTION: DO NOT OVER-TIGHTEN SCREWS!
10) Reinstall grilles.

Refer to owner's manual for further installation instructions.